

AS SHIPPED [6MC**AUGUST 08, 2012**For Help Desk Phone Numbers [Click here](#)Sales Model: 3608
DITABuild Date: 1997-10-
08

Part Numbers						
Reference Number	Eng Chg	Quantity	ASM LESS	Set Type	Description	BreakDown
SA0866	01	1	I		EPG - MINAHASA GOLDMINE (1) 3	BreakDown...
- 7E7008	10	1	I		3608 ENGINE AR. - BASIC	BreakDown...
- 0T9866	00	1	I		2710 BKW @ 1000 RPM (3634 BHP)	BreakDown...
- 1W0803	12	1	I		LINES GP-OIL COOLER (B)	BreakDown...
- 1W0806	05	1	I		FILTER GP-CENTRIFUGAL LUBE	BreakDown...
- 1W0809	08	1	I		COOLER GP-ENGINE OIL	BreakDown...
- 1W0820	05	1	I		PUMP GP-FUEL TRANSFER	BreakDown...
- 1W0826	09	1	I		LIFTING GP	BreakDown...
- 1W0856	09	1	I		LINES GP - FUEL INJECTION	BreakDown...
- 1W0894	05	1	I		MOTOR GP-AIR START.(A) (STDROT)	BreakDown...
- 1W9874	10	1	I		FITTING GP-EXHAUST (ADAPTER)	BreakDown...
- 2W1242	04	1	I		DRIVE GP - GOV	BreakDown...
- 2W2664	11	1	I		TANK GP - EXPANSION (B)	BreakDown...
- 2W2678	01	1	I		CONNECTION GP-WATER (FLANGE)	BreakDown...
- 2W2680	06	1	I		FLEXIBLE FITTING	BreakDown...
- 2W2681	04	1	I		FITTING GP-EXHAUST (EXPANDER)	BreakDown...
- 2W2682	04	1	I		FLANGE GP-EXHAUST (SIZE 18M)	BreakDown...
- 2W2683	02	1	I		FILTER GP-PRIMARY FUEL (DUPLEX)	BreakDown...
- 2W2696	10	1	I		LINES GP-INSTRU.PANEL (FRONT)	BreakDown...
- 2W2728	08	1	I		GAGE GP - (MANIFOLD AIR)	BreakDown...
- 2W2789	02	1	I		MOUNTING GP - INSTRUMENT	BreakDown...
- 2W2822	02	1	I		GAGE GP	BreakDown...
- 2W3343	11	1	I		LINES GP-WATER (REMOTE)	BreakDown...
- 2W3363	10	1	I		PUMP GP-FUEL PRIMING (R.H.)	BreakDown...
- 2W5577	03	1	I		PUMP GP-ENGINE OIL	BreakDown...
- 2W5896	08	1	I		LINES GP-FUEL FILTER (RH SERV)	BreakDown...
- 2W6304	05	1	I		LINES GP-WATER (OIL COOLER)	BreakDown...
- 2W7119	01	1	I		CONNECTION GP-WATER (OR EM.OIL)	BreakDown...

- 2W7889	06	1	I	FITTING GROUP - EXHAUST	BreakDown...
- 4P2268	00	1	I	DRAIN GP - OIL PAN	BreakDown...
- 4P2373	06	1	I	LINES GP - FILTER	BreakDown...
- 4P6119	00	1	I	LINES GP - INSTR	BreakDown...
- 4P7014	04	1	I	TURBO GP - BASIC	BreakDown...
- 4P9191	04	1	I	INDICATOR GP - LIQ	BreakDown...
- 4W0365	01	1	I	COVER GP - (SCAVENGE PUMP)	BreakDown...
- 4W1935	05	1	I	REGULATOR GP-TEMPERATURE	BreakDown...
- 4W5982	02	1	I	GAGE GP (AIR CLEANER)	BreakDown...
- 4W8071	02	1	I	CONNECTION GP	BreakDown...
- 4W9050	01	1	I	CONNECTION GROUP	BreakDown...
- 5P2506	00	1	I	LITERATURE GP - ENGLISH	BreakDown...
- 5Z9840	00	1	I	FASTENER GP - BOX	BreakDown...
- 7C0533	01	1	I	MTG. GP.- GEN. BASE (ISOLATOR)	BreakDown...
- 7C1903	05	1	I	PUMP GP - FUEL INJ.	BreakDown...
- 7C2145	01	1	I	COVER GP	BreakDown...
- 7C4180	07	1	I	LINES GP - AIR	BreakDown...
- 7C4699	03	1	I	LINES GP - INSTRUMENT	BreakDown...
- 7C5269	04	1	I	MOUNTING GROUP - ENGINE	BreakDown...
- 7C5690	01	1	I	STARTER - MOTOR	BreakDown...
- 7C6721	02	1	I	LINES GROUP - INSTR.	BreakDown...
- 7C6722	01	1	I	LINES GROUP - INSTR.	BreakDown...
- 7C7897	00	1	I	FITTING GROUP	BreakDown...
- 7C8780	04	1	I	LINES GP - AIR	BreakDown...
- 7C9064	09	1	I	PANEL GROUP - INSTRU.	BreakDown...
- 7E2782	02	1	I	LINES GP - WATER	BreakDown...
- 7E2784	01	1	I	LINES GP - WATER	BreakDown...
- 7E4389	00	1	I	GAGE GP	BreakDown...
- 7E4449	02	1	I	LINES GP - WATER	BreakDown...
- 7E5042	04	1	I	LINES GP - OIL	BreakDown...
- 7E6244	02	1	I	PUMP GP - PRELUBE	BreakDown...
- 7E7173	00	1	I	CONTACTOR GP	BreakDown...
- 7E8180	01	1	I	PUMP GP - WATER	BreakDown...
- 7N4885	10	1	I	WATER LEVEL SWITCH GAUGE	BreakDown...
- 5N3700		1	I	*****FACTORY NOTE*****	BreakDown...
- 7W0127	04	1	I	DAMPER GP	BreakDown...
- 7W1145	06	1	I	SENSOR GP - ELEC.	BreakDown...
- 7W1543	10	1	I	FILTER GP - FUEL	BreakDown...
- 7W1608	07	1	I	METER GP - HOUR (REMOTE)	BreakDown...
- 7W1841	00	1	I	HOSE ASSEMBLY	BreakDown...
- 7W4916	09	1	I	ADAPTER GP - AIR CLEANER	BreakDown...

- 7W5890	00	1	I	FILM - ROTATION	BreakDown...
- 7W6583	03	1	I	GUARD GP-DAMPER(2-30 " NARROW)	BreakDown...
- 7W7543	01	1	I	LINES GP - INSTR.	BreakDown...
- 8N8486	04	1	I	SILENCER GP-STARTING AIR.	BreakDown...
- 9Y0207	01	1	I	LINES GROUP - INSTR.	BreakDown...
- 9Y1851	00	1	I	GEAR GP - RING	BreakDown...
- 9Y3298	03	1	I	LINES GP - LUBE OIL	BreakDown...
- 9Y4252	01	1	I	BARRING GROUP	BreakDown...
- 9Y6182	01	1	I	FLYWHEEL GROUP	BreakDown...
- 9Y9273	07	1	I	LINES GP - AIR	BreakDown...
- 9Y9588	00	1	I	REGULATOR GROUP -G	BreakDown...
- 1190805	02	1	I	GUARD GP. - COUPLING	BreakDown...
- 1210248	01	1	I	CONTACTOR GP.-LO FUEL PRESS AL	BreakDown...
- 1210250	01	1	I	CONTACTOR GP.-LO AIR ST PR ALM	BreakDown...
- 1219708	05	1	I	CONTACTOR GP.-CUST. MTD-COMPL	BreakDown...
- 1234634	02	1	I	CONTACTOR GP.-HI DIST FUEL TEM	BreakDown...
- 1239787	01	1	I	MTG. GP. - GENERATOR	BreakDown...
- 1263577	04	1	I	MANIFOLD GP. - EXHAUST (3608)	BreakDown...
- 1315452	03	1	I	2301A LOAD SHARING GOVERNOR	BreakDown...
- 1339196	00	1	I	GAGE AS.-OIL LEVEL	BreakDown...
- 1070077	00	1	I	GUARD GP - FLYWHEEL	BreakDown...
- 1345927	00	1	I	COVER - TARP (3608)	BreakDown...
- 1358086	00	1	I	SHIELD GP.-MANIFOLD (3608 SOFT)	BreakDown...
- 1367926	00	1	I	CLEANER GP. - AIR(EPOXY)	BreakDown...
- 1377138	00	1	I	ACTUATOR AS.-EGB13P-FWD/ETS	BreakDown...
- 1379977	00	1	I	SHUT OFF GP. - EGB13P	BreakDown...
- 1391460	00	1	I	VALVE GP - MANUAL	BreakDown...
- 1447647	00	1	I	SENSOR GP. - PARTICLE DETECTOR	BreakDown...
- 1125539	00	1	I	FITTING GP.-PRIMARY FILTER	BreakDown...
- 1459075	00	1	I	LINES GP. - OIL	BreakDown...
- 1531949		1	I	PACKAGING AR. - MINAHASA	BreakDown...
OP1502		1	I	GEN SET TORS VIB ANALYSIS	BreakDown...
OP1914		1	I	DOMESTIC PACK FOR EXPORT	BreakDown...
OP9271		1	I	TARP OVER SHRINK WRAP ENGINE	BreakDown...
3L0391		1	I	TEST REPORT-CERT.	BreakDown...

DYNOMOMETER

Adjustments

Reference Number	Eng Chg	Quantity	ASM LESS	Set Type	Description	BreakDown
1W0021	16	8			HEAD GP-CYL	BreakDown...
1W0023	12	1			HSG GP-FRT	BreakDown...
1W0027	09	6			COVER GP-VALVE	BreakDown...
1W0603	04	1			HOUSING AS.	BreakDown...
1W0607	02	1			PINION AS	BreakDown...
1W0789	15	8			MECHANISM GP	BreakDown...
1W0790	08	1			GEAR GP-FRT.	BreakDown...
1W0796	06	1			MOUNTING GP-ENG	BreakDown...
1W0798	19	1			FILTER GP-OIL	BreakDown...
1W0800	08	1			BREATHER GP	BreakDown...
1W0802	09	1			LINES GP-ENG OIL	BreakDown...
1W0803	12	1			LINES GP-OIL	BreakDown...
1W0804	07	1			VALVE GP-PRIORIT	BreakDown...
1W0806	05	2			FILTER GP-CENTRI	BreakDown...
1W0809	08	1			COOLER GP	BreakDown...
1W0815	05	1			MOUNTING GP	BreakDown...
1W0820	05	1			PUMP GP.FUEL	BreakDown...
1W0826	09	1			LIFTING GP	BreakDown...
1W0834	08	1			CRANKSHAFT GP.	BreakDown...
1W0839	11	1			PAN GP-OIL	BreakDown...
1W0856	09	1			LINES GP-FUEL	BreakDown...
1W0894	05	1			MOTOR GP	BreakDown...
1W1076	01	1			COVER AS	BreakDown...
1W1952	01	1			BRACKET AS	BreakDown...
1W2470	09	8			LIFTER GP	BreakDown...
1W3382	05	1			COVER GP	BreakDown...
1W3645	09	5			VALVE GP	BreakDown...
1W4191	05	2			FILTER GP.	BreakDown...
1W8260	01	1			BRACKET AS	BreakDown...
1W8410	02	8			SHAFT AS	BreakDown...
1W8490	03	8			PLATE AS	BreakDown...
1W9874	10	1			FITTING GP-EXH-A	BreakDown...
2W1242	04	1			DRIVE GP-GOVNR	BreakDown...
2W2664	11	1			TANK GP	BreakDown...
2W2678	01	2			CONNECTION GP-H	BreakDown...
2W2680	06	1			FITTING GP-EXHAU	BreakDown...
2W2681	04	1			FITTING GP-EXHAU	BreakDown...
2W2682	04	3			FLANGE GP-EXHAUS	BreakDown...
2W2683	02	1			FILTER GP-PRIME	BreakDown...
2W2696	10	1			LINES GP-INST	BreakDown...
2W2724	04	1			TACHOMETER GP	BreakDown...
2W2728	08	1			GAGE GP-AIR	BreakDown...
2W2751	01	1			VALVE GP	BreakDown...
2W2789	02	1			MTG. GP-INST. PL	BreakDown...

2W2822	02	1	GAGE GP-PRESSURE	BreakDown...
2W2945	02	1	LUBRICATOR GP	BreakDown...
2W3343	11	1	LINES GP-WATER	BreakDown...
2W3363	10	1	PUMP GP-FUEL	BreakDown...
2W5577	03	1	PUMP GP	BreakDown...
2W5896	08	1	LINES GP-FUEL	BreakDown...
2W6304	05	1	LINES GP-WATER	BreakDown...
2W7119	01	1	CONNECTION GP-WTR	BreakDown...
2W7889	05	1	FITTING GP	BreakDown...
4P0401	06	8	PISTON GP	BreakDown...
4P2268	00	1	DRAIN GP	BreakDown...
4P2351	01	1	HSG.AS.-FRT	BreakDown...
4P2373	06	1	LINES GP-FILTER	BreakDown...
4P6119	00	1	LINES GP-INST.	BreakDown...
4P7001	00	1	HOUSING GP-REAR	BreakDown...
4P7003	01	1	COVER GP (CAM)	BreakDown...
4P7014	04	1	TURBO GP - BASIC	BreakDown...
4P7029	03	1	CONTROL GP-FUEL	BreakDown...
4P7988	00	1	HOUSING AS.	BreakDown...
4P8017	00	1	LINES GP-TURBO	BreakDown...
4P9185	00	1	COVER AS.	BreakDown...
4P9191	04	1	DETECTOR GP.	BreakDown...
4W0012	01	1	MOUNTING GP	BreakDown...
4W0345	05	8	PLUG GP	BreakDown...
4W0365	01	1	COVER GP	BreakDown...
4W0379	00	2	INDICATOR AS.	BreakDown...
4W0543	03	8	COVER GP	BreakDown...
4W0695	04	1	MOTOR GP-BSC	BreakDown...
4W1935	05	1	REGULATOR GP	BreakDown...
4W3933	01	1	FLANGE AS	BreakDown...
4W4623	05	1	PUMP GP-BSC	BreakDown...
4W5421	02	1	FILTER GP	BreakDown...
4W5982	02	1	GAGE GP-AIR CLEA	BreakDown...
4W6273	01	1	SUPPORT AS	BreakDown...
4W8071	02	1	CONNECTION GP-WTR	BreakDown...
4W9050	01	2	CONNECTION GP-H	BreakDown...
5P2506	00	1	LITERATURE GP.-E	BreakDown...
5P3591	05	4	ADAPTER GP	BreakDown...
7C0533	01	8	MTG GP-GEN BASE	BreakDown...
7C1124	00	1	TUBE AS	BreakDown...
7C1128	00	2	SHAFT AS	BreakDown...
7C1568	00	1	PLATE AS-CAM	BreakDown...
7C1903	04	8	PUMP GP.-FUEL	BreakDown...
7C2122	02	2	DAMPER GP-BSC	BreakDown...
7C2145	01	1	COVER GP-EXH.ADA	BreakDown...
7C4180	07	1	LINES GP-AIR	BreakDown...
7C4699	03	1	LINES GP-INST	BreakDown...
7C5269	04	1	MOUNTING GP-ENG	BreakDown...

7C5690	01	1	STARTER - MOTOR	BreakDown...
7C6721	02	1	LINES GP-INSTR	BreakDown...
7C6722	01	1	LINES GP-INSTR	BreakDown...
7C7897	00	1	FITTING GP	BreakDown...
7C7974	03	1	CRANKSHAFT AS	BreakDown...
7C8780	04	1	LINES GP-AIR	BreakDown...
7C9002	04	1	PANEL GP-INSTR	BreakDown...
7C9064	09	1	PANEL GP-INST.	BreakDown...
7E1659	01	1	CAP GP OIL	BreakDown...
7E2782	02	1	LINES GP-WATER	BreakDown...
7E2784	01	1	LINES GP-WATER	BreakDown...
7E3100	02	1	AFTERCOOLER GP	BreakDown...
7E3172	03	2	PUMP GP-WATER	BreakDown...
7E3974	00	1	PUMP GP.	BreakDown...
7E4389	00	1	GAGE GP-AIR	BreakDown...
7E4447	01	1	COVER GP	BreakDown...
7E4449	01	1	LINES GP-WATER	BreakDown...
7E5042	04	1	LINES GP-PRELUBE	BreakDown...
7E6244	02	1	PUMP GP-PRELUBE	BreakDown...
7E6554	00	1	PUMP GP-LINES	BreakDown...
7E7008	10	1	ENGINE AR	BreakDown...
7E7163	00	1	SHAFT AS-CAM DR	BreakDown...
7E7173	00	1	CONTACTOR GP	BreakDown...
7E7200	00	1	CAMSHAFT GP	BreakDown...
7E7201	00	1	CAMSHAFT AS	BreakDown...
7E8127	00	1	JOURNAL AS-CAM	BreakDown...
7E8130	00	2	JOURNAL AS-CAM	BreakDown...
7E8131	00	2	JOURNAL AS-CAM	BreakDown...
7E8132	00	1	JOURNAL AS-CAM	BreakDown...
7E8133	00	1	JOURNAL AS-CAM	BreakDown...
7E8173	00	1	GEAR AS	BreakDown...
7E8174	00	1	GEAR AS	BreakDown...
7E8180	01	2	PUMP GP-WATER	BreakDown...
7E9012	05	8	HEAD GP.	BreakDown...
7N4885	10	1	GAGE GP-WATER LE	BreakDown...
7W0127	04	1	DAMPER GP.	BreakDown...
7W1145	06	2	SENSOR GP-ELEC.	BreakDown...
7W1282	03	1	PUMP GP-FUEL	BreakDown...
7W1543	10	1	FILTER GP-FUEL	BreakDown...
7W1608	07	1	METER GP-HOUR	BreakDown...
7W1841	00	2	HOSE ASSEMBLY	BreakDown...
7W2970	01	1	SUPPORT AS	BreakDown...
7W4916	09	1	ADAPTER GP-AIR-C	BreakDown...
7W5890	00	1	FILM - ROTATION	BreakDown...
7W6583	03	1	GUARD GP-DAMPER	BreakDown...
7W7543	01	1	LINES GP-INST	BreakDown...
7W8431	01	4	SUPPORT AS	BreakDown...
7W9036	00	1	ADAPTER AS	BreakDown...

7W9683	02	1	SEAL GP-CSHFT -B	BreakDown...
7X1173	04	1	VALVE GP-SOLENOI	BreakDown...
8N8486	04	1	SILENCER GP	BreakDown...
8N9071	00	1	VALVE AS	BreakDown...
9Y0207	01	1	LINES GP-INST	BreakDown...
9Y1851	00	1	GEAR GP-RING	BreakDown...
9Y3298	03	1	LINES GP-LUB OIL	BreakDown...
9Y4252	01	1	BARRING GP.	BreakDown...
9Y4254	00	1	BRACKET AS.	BreakDown...
9Y6182	01	1	FLYWHEEL GP	BreakDown...
9Y9273	07	1	LINES GP-AIR	BreakDown...
9Y9345	03	1	GEAR GP-REAR	BreakDown...
9Y9346	00	1	SHAFT AS.	BreakDown...
9Y9348	01	1	GEAR AS.	BreakDown...
9Y9588	00	1	REGULATOR GP	BreakDown...
9Y9926	00	1	GUIDE GP.	BreakDown...
9Y9927	03	1	FILLER GP OIL	BreakDown...
9Y9992	02	1	PUMP GP PRELUBE	BreakDown...
1005681	01	1	VALVE GP	BreakDown...
1070077	00	1	GUARD GP-FLY	BreakDown...
1085946	00	1	PANEL GP-CNTOR	BreakDown...
1125539	00	1	FITTING GP	BreakDown...
1190805	02	1	GUARD GP-CPLG	BreakDown...
1210243	00	1	CONTACTOR GP	BreakDown...
1210244	01	1	CONTACTOR GP	BreakDown...
1210245	01	1	CONTACTOR GP	BreakDown...
1210246	01	1	CONTACTOR GP	BreakDown...
1210247	01	1	CONTACTOR GP	BreakDown...
1210248	01	1	CONTACTOR GP	BreakDown...
1210250	01	1	CONTACTOR GP	BreakDown...
1210597	02	1	DETECTOR GP-LIQ	BreakDown...
1216023	01	1	BLOCK GP-CYL	BreakDown...
1219708	05	1	CONTACTOR GP	BreakDown...
1234629	01	1	CONTACTOR GP	BreakDown...
1234630	01	1	CONTACTOR GP	BreakDown...
1234631	01	1	CONTACTOR GP	BreakDown...
1234632	01	1	CONTACTOR GP	BreakDown...
1234633	01	1	CONTACTOR GP	BreakDown...
1234634	02	1	CONTACTOR GP	BreakDown...
1239787	01	1	MTG GP-GENERATOR	BreakDown...
1254340	01	1	DETECTOR GP-LIQ	BreakDown...
1263577	04	1	MANIFOLD GP	BreakDown...
1267252	00	1	MTG GP-CONTACTOR	BreakDown...
1285682	00	8	ARM GP-V ROCKER	BreakDown...
1311459	00	1	STRAINER GP	BreakDown...
1315452	03	1	2301A LOAD SHARI	BreakDown...
1329323	00	1	CLEANER GP-AIR	BreakDown...
1329324	00	5	PRECLEANER GP	BreakDown...

1339196	00	1	GAGE AS.-OIL LEV	BreakDown...
1345927	00	1	COVER - TARP (36	BreakDown...
1358086	00	1	SHIELD GP.-MANIF	BreakDown...
1367926	00	1	CLEANER GP-AIR	BreakDown...
1374729	01	8	INJECTOR GP-FUEL	BreakDown...
1377138	00	1	ACTUATOR AS.-EGB	BreakDown...
1379977	00	1	SHUT-OFF GP-RACK	BreakDown...
1391460	00	8	VALVE GP-MANUAL	BreakDown...
1447647	00	1	SENSOR GP	BreakDown...
1459075	00	1	LINES GP-ENG OIL	BreakDown...
1507891	00	1	SHUT-OFF GP-AIR	BreakDown...
1531949	00	1	PACKAGING AR. -	BreakDown...
